

Parts List-Numerical

Part Number	Description
GAR-00203	Water Tank (GB/GT550)
GAR-00701-D	Liquid Coolant Regulator Valve (Water-cooled)
GBR-00111	Evaporator Shim (10)
GBR-00113	Evaporator Spacer, "C" or "HK", 4 required
GBR-00126	Evaporator Spacer, "K", 4 required
GBR-00148	Evaporator (All GB/GT550, "C")
GBR-00153	Evaporator (All GB/GT550, "K")
GBR-00167	Evaporator (All GB/GT550 "HK")
GBR-00200	Water Plate (All GB/GT550 "C")
GBR-00202	Water Deflector (All GB/GT550)
GBR-00208-B	Water Pump, 115/60 (GB421/431/441/451/GT551)
GBR-00208-FF-B	Water Pump, 220-240/50 (GB427/437/447/457/627/637/647/657)
GBR-00223	Water Plate Plugs (12)
GBR-00245	Water Tank Outlet Screen (All GB/GT550)
GBR-00270	Water Plate (All GB/GT551 "HK" & "K")
GBR-00282-06	Water Plate Bracket Kit (front & rear)
GBR-00403	Water Distribution Tube Kit (All GB/GT550)
GBR-00580	Cam Shaft Shim (2 thin-2 thick)
GBR-00668	Ice Chute, GB only
GBR-00813	Bin Thermostat 120" cap. tube (extra long when required)
GBR-00814	Actuator Thermostat
GBR-00826	Capacitor 1.5 Mfd. <u>Old</u> act. motor, Dir. of Rot. & 220-240/50 Volt. Red.
GBR-00837	Cold Water Thermostat
GBR-00856	Bin Thermostat 66" cap. tube (standard)
GBR-00897	Actuator Toggle Switch
GBR-00909	Water Plate Spring (2 req'd.)
GBR-00937	Cam Shaft Bracket (2 req'd.)
GBR-00942	Cam Shaft (All GB/GT550)
GBR-00949	Rear Cam
GBR-00959	Roll Pin (10)
GBR-00969	Front Cam
GBR-00972	Actuator Motor (GB1220 Upper) <u>Old</u> , See Actuator Motor application chart for replacement requirements.
GBR-01353	Air Cooled Condenser (GB420A/430A/440A/450A/GT330A/340A/350A)
GBR-01360	Fan Blade (GB420A/430A/440A/GB620A/630A/640A)
GBR-01362	Fan Support (GB421A/431A/441A)
GBR-01363	Fan Shroud (GB420A/430A/440A)

Parts List-Numerical

Part Number	Description
GBR-01364	Fan Motor, 115/60 (GB421A/431A/441A)
GBR-01375	Water Solenoid Valve, 120V coil (GB421/431/441/451/GT551)
GBR-01376-FF	Water Sol., 240V coil (GB4X4/4X7/6X4/6X7/12X4/12X5/12X8/GT554)
GBR-01379	Water Solenoid Valve Inlet Strainer
GBR-01385-01	Start Relay (GB624/627 Cope. RSL5)
GBR-01385-03	Run Capacitor (GB441/634/637/647)
GBR-01395-05	Run Capacitor (GB1224)
GBR-01498	Pump & Defrost Switch (GB1220/1240/1250 Lower)
GBR-01889	Refrigerant Inlet Fitting 3/8" (Remote condenser models)
GBR-01890	Refrigerant Discharge Fitting 1/2" (Remote condenser models)
GBR-02087	Hose Kit (All models)
GBR-02290	Check Valve (Remote cond. models & GB1220W/1240W/1250W)
GBR-02343	Receiver (GB1220W/1240W/1250W)
GBR-02351	Head Pressure Control Valve (Remote cond. models, R-502/R-404a)
GBR-02353-01	Start Relay (GB1224/1244)
GBR-02353-02	Start Cap. (GB441/1224)
GBR-02354	High Pressure Cutoff, Auto. reset, R-502 (GB420/620)
GBR-02359	Expansion Valve (GT550/All GB except 450)
GBR-02750	Drier, 3 cu. in. (All self-contained "A" & "W" models except GB1200W)
GBR-03110-01	Modified Rotor (GB1220 Upper) <u>Old</u> act. motor
GBR-03153	Actuator Motor <u>Old</u> , OBS., See actuator motor application chart.
GBR-03230	Adjusting Screw (GT330/340/350), Pump & Defrost Switch
GBR-03347	Air Cooled Condenser (GB620A)
GBR-03370	Pump Down Controller (Remote cond. models), Cap. tube connection.
GTR-00204-B	Water Pump, 115/60 (GT331/341/351)
GTR-00206-FF-B	Water Pump 220-240/50 (GT337/347)
GTR-00221	Water Plate (GT330/340/350 "C")
GTR-00222	Water Plate (GT330/340/350 "HK" & "K")
GTR-00373-02	Start Capacitor (GB421 Cope. RSU5)
GTR-00705	Liquid Cooled Condenser (GB420W/620W)
GYR-00201	Water Tank (GT330/340/350)
GYR-00202	Water Deflector (GT330/340/350)
GYR-00219	Water Tank Outlet Screen (GT330/340/350)

Parts List-Numerical

Part Number	Description
GYR-00361	Water Solenoid Valve, 120V coil (GT331/341/351)
GYR-00362-FF	Water Solenoid Valve, 240V coil (GT334/337/344/347/354/357)
102 1007 01	Relay Socket, 2-pole (GB430R/440R/454R/620R/630R/640R/650R/1240/1250/GT550R)
102 1007 02	Relay Socket, 3-pole (GB1220/1240 before Sept., '96)
102 1008 01	Valve Body (GT330/340/350 & GB430R/440R/GT550R hot gas)
102 1010 01	Valve Body (all applications except GT330/340/350 & GB430R/440R/454R/1220/1240/1250 hot gas)
102 1010 02	Valve Body (GB1220/1240/1250 hot gas)
102 1011 01	Coil, 120V (GB421/431/441/451/GT331/341/351/551)
102 1012 01	Coil, 240V (GB427/434/437/444/447/454/457/620/630/640/650/1220/1240/1250/GT334/337/344/347/354/357/554)
102 1014 01	Fan Motor, 115/60 (GB451A/GT331A/341A/351A/551A)
102 1014 02	Fan Motor, 220-240/50 (GB457A/657A/GT337A/347A/357A)
102 1015 01	Fan Motor, 208-230/60 (GB454A/654A/GT334A/344A/354A/554A)
102 1016 02	Fan Blade (GT330A/340A/350A/551A/554A/GB457A/650A)
102 1016 03	Fan Blade (GB451A/454A)
102 1018 02	Air Cooled Condenser (GB630A/640A/650A/1250A)
102 1018 03	Air Cooled Condenser (GT550A)
102 1020 01	Liquid Cooled Condenser (GB430W/440W/450W/GT550W)
102 1020 02	Liquid Cooled Condenser (GB1220W/1240W/1250W)
102 1020 03	Liquid Cooled Condenser (GT330W/340W/350W)
102 1020 04	Marine Liquid Cooled Condenser (MGB650W)
102 1020 05	Marine Liquid Cooled Condenser (MGB450W/MGT550W)
102 1020 06	Marine Liquid Cooled Condenser (MGT3XXW)
102 1021 01	Liquid Cooled Condenser (GB630W/640W/650W)
102 1023 01	Receiver (GB420R/430R/440R/620R/630R/640R/650R/GT550R)
102 1023 02	Receiver (GB1220R/1240R/1250R)
102 1025 02	Evaporator (GT330/340/350 "C")
102 1025 03	Evaporator (GT330/340/350 "HK")
102 1025 04	Evaporator (GT330/340/350 "K")
102 1035 01	Contactator, 120V coil (GB421/431/441/451/GT331/341/351/551)
102 1036 01	Contactator, 240V coil, 1-pole (GB427/434/437/444/447/454/457/620/630/640/650/1224/1244/1254/GT334/337/344/347/354/357/554)
102 1036 02	Contactator, 240V coil, 2-pole (GB1225/1245/1255/1258)
102 1037 01	Relay-Plug in, 2-pole/120V coil (GB421R/431R/441R/GT551R)

Parts List-Numerical

Part Number	Description
102 1037 02	Relay-Plug in, 3-pole/240V coil (GB1220/1240 before Sept., '96)
102 1038 01	Relay-Plug in, 2-pole/240V coil (GB624R/634R/644R/654R/1240 after Aug., '96/1250/GT554R)
102 1044 01	Run Capacitor (GB421 Cope. RSU5/GB431 Brist. M51B/GB434/454/457/GT331/334/341/344/GT354/357/554)
102 1047 02	Start Relay (GB434/634 Brist. M51B)
102 1047 03	Start Relay (GB437/637/647GT337)
102 1047 04	Start Relay (GB431/441/1254/GT331/341)
102 1047 05	Start Relay (GB644)
102 1047 06	Start Relay (GB454/GT334/344/354)
102 1047 07	Start Relay (GB447/GT347)
102 1047 08	Start Relay (GB444)
102 1047 09	Start Relay (GB451/GT351/551)
102 1047 10	Start Relay (GT357)
102 1047 11	Start Relay (GB457)
102 1047 12	Start Relay (GB657)
102 1047 13	Start Relay (GB654)
102 1047 14	Start Relay (GT554)
102 1048 01	Start Relay (GB421 Cope. RSU5)
102 1052 02	Pump-down Controller, Direct Conn. (GB454R/650R/1250R/GT550R)
102 1053 01	ICE-OFF-WASH Switch
102 1055 01	High Press. Cutoff, Manual Reset, R-502/404a (Cap. tube connection), (GB430/440/450/630/640/650/1220/1240/1250/GT330/340/350/550)
102 1066 01	Receiver (GB420/430/440/450/620/630/640/650/GT330/340/350/550W)
102 1071 01	Drier, 8 cu. in. (GB440R/454R/640R/650R/GT550R, and All GB1220/1240/1250)
102 1100 01	Drain Pan Assembly (All GB)
102 1100 02	Drain Pan/Chute (GT330/340/350)
102 1100 03	Drain Pan/Chute (GT330/340/350 Multiplex)
102 1100 04	Drain Pan (GT550)
102 1100 05	Ice Chute (GT550)
102 1127 02	Water Pump, 230/60 (GB434/444/454/624/634/644/654/1220/1240/1250/GT554)
102 1127 03	Water Pump, 230/60 (GT334/344/354)
102 1142 01	Liquid Level Control, 230V (GB427/434/437/444/447/454/457/620/630/640/650/1220/1240/1250/GT334/337/344/347354/357/554)
102 1154 02	Water Distribution Tube Kit (GT330/340/350)

Parts List-Numerical

Part Number	Description
102 1166 02	Check Valve-Harvest Regulator (GB430R/440R/454R/630R/640R/650R/1224R/1240R/1250R/GT550R)
102 1180 02	Actuator Motor (GT300) Old, OBS., use 102 1238 kit (see appl. chart)
102 1188 02	Expansion Valve (GB450/GT330/340/350)
102 1190 01	High Temperature Shutoff Thermostat (OBSOLETE, see EB#96002)
102 1191 09	Compressor (GB644 Brist.), OBS., use 102 1242 14 kit
102 1191 10	Compressor (GB434 Brist.), OBS., use 102 1242 18 kit
102 1191 11	Compressor (GT334 Brist.), OBS., use 102 1242 12 kit
102 1191 13	Compressor (GB441 Brist.), OBS., use 102 1242 15 kit
102 1191 14	Compressor (GB447 Brist.), OBS., use 102 1242 17 kit
102 1191 15	Compressor (GB647 Brist.), OBS., use 102 1242 16 kit
102 1191 16	Compressor (GT341 Brist.), OBS., use 102 1242 11 kit
102 1191 17	Compressor (GB1244 Brist.), OBS., use 102 1242 09 kit
102 1191 18	Compressor (GB1245 Brist.), OBS., use 102 1242 10 kit
102 1191 19	Compressor (GT344 Brist.), OBS., use 102 1242 12 kit
102 1191 20	Compressor (GB444 Brist.), OBS., use 102 1242 18 kit
102 1191 21	Compressor (GT551 Tec.)
102 1191 22	Compressor (GB1254 Tec.)
102 1191 23	Compressor (GB1255 Tec.)
102 1191 24	Compressor (GT351 Tec.)
102 1191 25	Compressor (GT357 Tec.)
102 1191 26	Compressor (GB654 Tec.)
102 1191 27	Compressor (GB657 Tec.)
102 1191 28	Compressor (GB451 Tec.)
102 1191 29	Compressor (GB457 Tec.)
102 1191 30	Compressor (GB1258)
102 1191 31	Compressor (GB454 Tec.)
102 1191 32	Compressor (GT354 Tec.)
102 1191 33	Compressor (GT554 Tec.)
102 1194 01	Start Relay (GB427 Cope. RSU5)
102 1195 01	Start Capacitor (GB427 Cope. RSU5)
102 1195 02	Start Capacitor (GB627, Cope. RSL5 & GB454/457/GT354/357/554)
102 1195 03	Start Capacitor (GB431//447/GT331//341/347 Brist.)
102 1195 04	Start Capacitor (GB634/637/647 Brist.)
102 1195 05	Start Capacitor (GB444/644/1244 Brist.)
102 1195 06	Start Capacitor (GB434/GT334/344 Brist.)

Parts List-Numerical

Part Number	Description
102 1195 08	Start Capacitor (GT351/551/GB451 Tec.)
102 1195 09	Start Capacitor (GB1254/GB654 Tec.)
102 1195 10	Start Capacitor (GB657 Tec.)
102 1196 01	Start Cap. (GB437/GT337 Brist. M51B) & (GB624 Cope. RSL5)
102 1197 01	Run Capacitor (GB624, Cope. RSL5 & GB444/447/644/GT347 Brist.)
102 1197 02	Run Capacitor (GB627 Cope. RSL5 & GB654/657 Tec.)
102 1197 04	Run Capacitor (GB437/GT337 Brist. M51B & GB451/GT351/551 Tec.)
102 1197 05	Run Capacitor (GB1244 Brist.)
102 1197 06	Run Capacitor (GB1254 Tec.)
102 1198 01	Overload Protector (GB421 Cope. RSU5)
102 1198 02	Overload Protector (GT351 Tec.)
102 1198 03	Overload Protector (GT551 Tec.)
102 1198 04	Overload Protector (GT357 Tec.)
102 1198 05	Overload Protector (GB457 Tec.)
102 1198 06	Overload Protector (GB451 Tec.)
102 1198 07	Overload Protector (GB454/GT554 Tec.)
102 1199 01	Overload Protector (GB427 Cope. RSU5)
102 1200 01	Overload Protector (GB624 Cope. RSL5)
102 1201 01	Drain Assembly (All GB)
102 1201 02	Drain Assembly (GT330/340/350)
102 1202 01	Front Panel (GB420/430/440/450/620/630/640/650)
102 1202 02	Front Panel (GB1220/1240/1250)
102 1202 03	Front Panel (GT330/340/350)
102 1202 07	Front Panel (GT550)
102 1203 01	Left End Panel (GB420/430/440/450/620/630/640/650/GT330/340/350)
102 1203 02	Left End Panel (GB1220/1240/1250)
102 1203 03	Left End Panel (GT550A)
102 1203 04	Left End Panel (GT550W/R)
102 1204 01	Right End Panel (GB420/430/440/450/620/630/640/650/GT330/340/350)
102 1204 02	Right End Panel (GB1220/1240/1250)
102 1204 03	Right End Panel (GT550A)
102 1204 04	Right End Panel (GT550W/R)
102 1205 01	Top Panel (All GB)
102 1205 02	Top Panel (GT330/GT340/350)
102 1205 03	Top Panel (GT550)
102 1206 01	Liquid Level Control, 115V (GB421/431/441/451/GT331/341/351/551)

Parts List-Numerical

Part Number	Description
102 1207 01	Stacking Kit (All GB)
102 1207 03	Stacking Kit (GT330/340/350 on GT330/340/350 or GT330/340/350 CLASSIC on GT300 Electronic)
102 1207 04	Stacking Kit (GT400/500/600 Electronic on GT330/340/350 CLASSIC)
102 1209 01	Actuator Motor Shaft Extension (All CLASSIC GB & GT550)
102 1210 01	Front Cam Pin (5)
102 1211 01	Ice Deflector (All GB)
102 1212 01	Fan Motor, 208-240/50-60, Retrofit Kit (see E.B. #02001) (GB427A/434A/437A/444A/447A/620A/630A/640A)
102 1213 01	Fan Support (GB427A/434A/437A/444A/447A)
102 1214 01	Fan Support (GB620A/630A/640A)
102 1214 02	Fan Support (GB450A/GT330A/340A/350A)
102 1214 03	Fan Support (GT550A)
102 1214 04	Fan Support (GB650A/1250A)
102 1215 01	Fan Shroud (GB624A/627A)
102 1215 02	Fan Shroud (GB630A/640A/650A)
102 1215 03	Fan Shroud (GT330A/340A/350A/GB450A)
102 1215 04	Fan Shroud (GT550A)
102 1216 01	Probes, Cap & Tube (All GB & GT550)
102 1216 02	Probes, Cap & Tube (GT330/340/350)
102 1217 01	Pump & Defrost Switch (all applications-see EB#96001)
102 1220 01	Harvest Regulator Valve, Remote Condenser models (GB430R/440R/454R/630R/640R/650R/1220R/1240R/1250R/GT550R)
102 1221 01	Cam Shaft (GT330/340/350)
102 1222 01	Cam Shaft Bracket-Front (GT330/340/350)
102 1223 01	Capacitor, 2 mfd. (GB434/444/624/634/644/1220/GT334 OLD actuator motor), 208-230/60 Voltage Reduction only.
102 1238 01	Actuator Motor Kit <u>New</u> , All 115/60 CLASSIC models
102 1238 02	Actuator Motor Kit <u>New</u> , All 208-230/60 & 220-240/50 CLASSIC models
102 1239 02	Timer, 230V (GB1220/1240/1250) <u>New</u> act. motor
102 1241 01	Capacitor 4 Mfd. <u>New</u> 115 Volt act. motor
102 1241 02	Capacitor 1 Mfd. <u>New</u> 230 Volt act. motor
102 1242 01	Compressor Retrofit Kit (GT331) OBS., use 102 1242 11
102 1242 02	Compressor Retrofit Kit (GB421/431) OBS., use 102 1242 15
102 1242 03	Compressor Retrofit Kit (GB624/634) OBS., use 102 1242 14
102 1242 04	Compressor Retrofit Kit (GB427/437) OBS., use 102 1242 17

Parts List-Numerical

Part Number	Description
102 1242 05	Compressor Retrofit Kit (GB627/637) OBS., use 102 1242 16
102 1242 06	Compressor Retrofit Kit (GB1224) OBS., use 102 1242 09
102 1242 07	Compressor Retrofit Kit (GT337) OBS., use 102 1242 13
102 1242 09	Compressor Retrofit Kit (GB1224/1244 1 Ph. Bristol to Tecumseh)
102 1242 10	Compressor Retrofit Kit (GB1225/1245 3 Ph. Bristol to Tecumseh)
102 1242 11	Compressor Retrofit Kit (GT331/341 Bristol to Tecumseh)
102 1242 12	Compressor Retrofit Kit (GT334/344 Bristol to Tecumseh)
102 1242 13	Compressor Retrofit Kit (GT337/347 Bristol to Tecumseh)
102 1242 14	Compressor Retrofit Kit (GB624 Cope./634/644 Bristol to Tecumseh)
102 1242 15	Compressor Retrofit Kit (GB421 Cope./431/441 Bristol to Tecumseh)
102 1242 16	Compressor Retrofit Kit (GB627 Cope./637/647 Bristol to Tecumseh)
102 1242 17	Compressor Retrofit Kit (GB427 Cope./437/447 Bristol to Tecumseh)
102 1242 18	Compressor Retrofit Kit (GB434/444 Bristol to Tecumseh)
102 1247 01	Act. Motor Synchronization Kit (GB1220W/1240W before Sept., '96)
102 1247 02	Act. Motor Synchronization Kit (GB1220R/1240R before Sept., '96)
102 1252 01	Act. Switch Retro. kit (GB1220 w/102 1247 kit/GB1240 before Sept., 96)
102 1253 01	Crankcase Heater, 240V (GB454R/650R/GT554R)
102 1254 01	Ice Chute, GB Stainless Steel
102 1256 01	Manifold Kit, MGB 3-high
102 1262 01	Replacement Gasket, MGB-SK
102 1264 01	Expansion Valve, GBO12XCPI, R-22
102 1265 01	Panel Screws, #8-18 S.S. (Pkg. of 10)
102 1266 01	Liquid Line Solenoid Valve & Coil (GBO12XCPI)
102 1267 01	Suction Line Solenoid Valve & Coil (GBO12XCPI)
102 1268 01	Drain Tube (GT550)
102 1269 01	Bin Door Kit (B-650)
102 1270 01	Bin Door Kit (B-950)
102 1271 01	Cam Shaft (GB450/650/1250/GT550)
102 1272 01	Cam Shaft (GT350)
102 1273 01	Bin Cover, Right Side (GT on B-550)
102 1274 01	Condenser Fan Motor, 230/50-60/50W (GB1250A)
102 1275 01	Condenser Fan Blade, 11" Dia. (GB1250A)

Parts List-Numerical

Part Number	Description
GBR-00856	Crushed & Cube Side Bin Thermostat (T-250/T-251 T-261/T-264)
GBR-00894	Transformer (AKD-125-FF)
TTR-02698	Gearmotor (AKD)
TTR-02711	Upper Bearing Assembly (AKD)
TTR-02716	Auger (AKD)
TTR-02717	Plastic Upper Bearing (AKD)
TTR-05144	Push Button Switch (AKD)
102 1007 01	Relay Socket (T-250/T-251 T-261/T-264)
102 1037 01	Relay-Plug in (T-251/T-261)
102 1038 01	Relay-Plug in (T-250/T-264)
102 1133 02	Crusher Motor (T-250/T-251 T-261/T-264)
102 1148 02	Drive Pulley-24 Tooth (T-250/T-251)
102 1148 03	Driven Pulley-72 Tooth (T-250/T-251)
102 1150 02	Drive Belt (T-250/T-251)
102 1152 02	Bearing (2 req'd.) (T-250/T-251)
102 1197 04	Run Capacitor (AKD)
102 1202 04	Front Panel (T-250/T-251 T-261/T-264)
102 1202 05	Front Panel-Upper (AKD)
102 1202 06	Front Panel-Bottom (AKD)
102 1217 04	Selector Switch (T-250/T-251 T-261/T-264)
102 1217 03	Interlock Switch (T-250/T-251 T-261/T-264)
102 1221 02	Selector Shaft (T-250/T-251 T-261/T-264)
102 1221 03	Drive Shaft (T-250/T-251 T-261/T-264)
102 1225 01	Selector Knob (T-250/T-251 T-261/T-264)
102 1226 01	Switch Actuator Link (T-250/T-251 T-261/T-264)
102 1227 01	Hopper Cap (T-250/T-251 T-261/T-264)
102 1230 01	Comb (T-250/T-251 T-261/T-264)
102 1231 01	Selector Plate (T-250/T-251 T-261/T-264)
102 1243 01	Spout (AKD)
102 1244 01	Spout Closure (AKD)
102 1245 01	Bottom Bearing Assembly (AKD)
102 1246 01	Straight Spout (AKD)
102 1257 01	Drive Pulley-13 Tooth (T-261/T-264)
102 1258 01	Driven Pulley-36 Tooth (T-261/T-264)
102 1259 01	Drive Belt (T-261/T-264)

Parts List-Numerical

Part Number	Description
102 1260 01	Bearing (2-req'd.) (T-261/T-264)
102 1261 01	Cutter Wheel Assembly (T-250/T-251 T-261/T-264)